

Figure 1-5 Inserting PC Digitizer Card

- 3** Replace the PC Digitizer back-panel cover plate screw to hold the card in place.
- 4** Replace the computer's cover as described in you computer's documentation.
- 5** Connect the Digitizer Adapter ([Figure 1-6](#)) to the back of the PC Digitizer card.




Figure 1-6 Digitizer Adapter

Making System Connections

- 1** Connect the following cables between the PC Digitizer card and the Agilent 70420A Test Set:
 - SMB (f) to BNC (m) cable between the PC Digitizer card adapter's `input_connector` and the Agilent 70420A Test Set's